



NOTES:

1. REFER TO 15.6 FOR REQUIRED CURB LANE AND SHOULDER WIDTHS.
2. FULL DEPTH SAWCUT IS REQUIRED AT LIMITS OF EXCAVATION FOR FULL-DEPTH PAVEMENT.
3. REFER TO GUIDELINES IN THE MUTCD FOR PAVEMENT MARKING DESIGNS.
4. FRONTAGE CHANNELIZATION IS DISCUSSED IN 13.2.

LEGEND

- FULL DEPTH PAVING
- MILL, WEDGE, AND RESURFACE FOR CROSS SLOPE TRANSITION

TYPICAL SITE ACCESS IMPROVEMENTS ENGINEERING ACCESS PERMITS